



PRESTIGE II

P0, P1, P1.1, P2, P3, P4, P5, P6, P7, P8
S1, S2, S3, S4, S5, S6, S7, S8, S9
S10, S11, S12, S13, S14, S15, S16, S17
PS12, PS13, PS14, PS32, PS33, PS34, PS35,
PS36, PS37, PS38, PS39, PS40



x2



x2



x2



x1



GB Fitting instructions

PL Instrukcja montażu

D Montageanleitung

F Instructions de montage

E Instrucciones de montaje

NL Montage-instructies

PT Instruções de Montagem

S Monteringsanvisning

FIN Asennusohje

EST Paigaldusjuhend

LAT Stiprināšanas instrukcija

LIT Pritvirtinimo instrukcijos

RU Инструкции по установке

CZ Návod na montáž

SK Návod na montáž

SLO Navodila za pritrdjevanje

HR Uputa za sastavljanje

HU A felszerelés módja

GR Οδηγίες συναρμολόγησης

RO Instrucțiuni de montare

TK Uydurma talimat











DK Montering instruktion









N Monteringsveiledning


I Istruzioni per il montaggio

UA Інструкція з монтажу

BY Інструкцыя па мантажы







AGURI

www.aguri.pl

